

COMBUSTIBLE GAS LEAK DETECTOR

TROUBLESHOOTING (55750)

Battery Check: Always check the batteries before any kind of repair. Weak batteries can create false readings.

| | ISSUE | SOLUTION |
|----|---|---|
| 1. | No keypad reaction | Replace the keypad (55750-KEY) |
| 2. | No leak readings | The sensor may need to be replaced (55750-SEN) (Sensors usually last around 20 hours) The probe may need to be replaced (55750-PR) |
| 3. | When the unit is not responding to any function | Look for loose or broken wires on the PC board May need to change the PC board (55750-PC) |
| 4. | LED lights do not show any readings | Replace the LED light (55100-LED) |
| 5. | Broken wire on PC board connecting to battery | Change the battery wire (55750-WIRE) |

REPLACEMENT PARTS

| DESCRIPTION | PART # | |
|--------------|------------|--|
| SENSOR | 55750-SEN | |
| PROBE | 55750-PR | |
| PC BOARD | 55750-PC | |
| KEY PAD | 55750-KEY | |
| LED LIGHT | 55100-LED | |
| BATTERY WIRE | 55750-WIRE | |