



Mastercool[®]
"World Class Quality"

ELECTRONIC CHARGING SCALE

98210 – A1 CALIBRATION PROCEDURE

1. Turn on scale. When "HELLO" is displayed press **"TARE/ENTER"** and **"CLEAR"** together. Display will show "SET-1."
2. Press **"TARE/ENTER."** Display will show SET-1 for kg calibration (for lb calibration press ↑ and SET-12 will display.) Press **"TARE/ENTER"** to confirm.
3. A " _ _ _ _ " 5 digit number will display. Press ↓.
4. Place calibration weight on scale.
5. Press ↑. Press **"TARE/ENTER."** Number displayed must match calibration weight. If a digit needs to be changed, press **"UNIT/SHIFT"** to activate digit (digit will blink.) Press ↑ or ↓ to change number. Repeat until all digits are changed.
6. When number displayed agrees with weight on scale press **"TARE/ENTER."** Calibration is complete. Once "HELLO" appears you can remove the weight.