



Mastercool[®]
"World Class Quality"

ELECTRONIC CHARGING SCALE

98210 – B1 CALIBRATION PROCEDURE

1. Press **ON/OFF** then immediately press **CLEAR + TARE/ENTER** simultaneously
2. You will then see **SET-1** on the LCD
3. Press **TARE/ENTER** again
You will then see **SET-11**
4. Press **TARE/ENTER** again
You will see **CAL** followed by a **5 digit number**
5. Press ↓ (down arrow)
You will see "ZERO" appear on the bottom left side of the LCD momentarily
6. Place a known calibrated weight on the platform
The number on the LCD will change to a new 5 digit number
7. After the new five digits become stabilized, Press ↑ (UP arrow)
8. You will see the word "**TARE**" appear in the middle of the LCD for a moment
9. Press **TARE/ENTER** again and you will see **GOOD**
10. Press **UNIT/SHIFT** and in combination with the ↑ and ↓ (UP/DOWN arrow keys) set the proper display that corresponds to the exact weight that is placed on the platform
11. When you have completed setting the display in agreement with the actual weight press **TARE/ENTER** again and you will see **GOOD** followed by **HELLO** and the actual weight amount will appear on the LCD again
12. Calibration is completed. Remove the weight from the platform and the scale should read 0.000